

Canopus Edius Pro 4

The Prev edit/next edit keys A & S seem to stop between edits on the time line, rather than go to the next/prev edit. There may be an update on Edius that fixes this.

Clear markers - there is no short-cut when in timeline to delete a single marker. The DEL button will delete a highlighted entry in the Marker window. The MC-20PRO short-cut is to clear all markers (shift+Alt+V).

The Delete button is the short-cut for DELETE key.

In Capture source OHCI, the Goto In (Q short-cut) does not properly seek the in point, but Goto out works. There may be an update on Edius that fixes this.

There is no obvious short-cut to switch to the device capture window (showing in the preview window) and back to the clip preview. The clip preview can be loaded by bringing up the bin window and then use play button (short-cut ENTER) to put it into the preview window. To bring the device capture window up, must choose from the file menu capture.. input settings, choose the format and press OK. Maybe there is another way, but can't use Alt+C+S since this is not a normal windows menu.